

Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Казахстан (7273)495-231

Таджикистан (992)427-82-92-69

Единый адрес для всех регионов: tmv@nt-rt.ru || <https://tenmars.nt-rt.ru/>

Измеритель индекса тепловой нагрузки TM-288



TM-288 HEAT STRESS WBGT Meter

As the Holy Infant, the temperature increasingly rises.

The chance of heatstroke increases dramatically in the moist heat environment.

This product, measuring in WBGT, provides real-time alarm immediately so as to prevent heatstroke in such the environment.

Functions:

- In compliance with JIS B 7922 Level 2
- Three applications: arm band, tripod, and hanging.
- High-sensitive capacitive humidity sensor and bandgap temperature sensor.
- Measure the WBGT, black-globe temp. (TG), Air temp. (TA), humidity (%RH).
- Low voltage indicator
- °C or °F selectable.
- With the plastic black-globe of the diameter Ø40mm.
- Three-stage WBGT alarm selectable: mute (buzzer not displayed), cyclic setting.
- Outdoor or indoor (default is OUT) measurement mode selectable.
- Sampling interval: per 20 seconds
- Operating wind speed: 0.3 m/s or above.

- Operation temperature and humidity: 0°C to +50°C, <80%RH (No condensation)
- Storage temperature and humidity: 0°C to +60°C, <70%RH (No condensation)

Wet Bulb Globe Temperature (WBGT)

Unit	Measuring range	Alarm Default	Alarm User Flashing
Caution	>21~25°C	mute	As exceeding the setting value, beep for 15 seconds
Extreme caution	>25~28°C	Beep for 4 seconds	
Danger	>28°C~31°C	Beep for 15 seconds	
Extreme Danger	>31°C	Beep for 3 second and pause for 2 seconds, repeat until 15 seconds	

Wet Bulb Globe Temperature (WBGT)

Unit	Measuring range	Resolution	tolerance range 15~40°C
°C	0~50.0	0.1	±2.0
°F	32.0~122.0	0.1	±3.6

※
Indoor & outdoor without sunshine "IN" :WBGT = (0.7×WET)+(0.3×TG)
Outdoor in sunshine "OUT" :WBGT=(0.7×WET)+(0.2×TG)+(0.1×TA)

Air temperature (TA)

Unit	Measuring range	Resolution	Tolerance @15~40°C
°C	0~50.0	0.1	±0.6
°F	32.0~122.0	0.1	±1.1

Black-globe temperature (TG)

Unit	Measuring range	Resolution	Tolerance @15~40°C
°C	0~80.0	0.1	±0.6
°F	32.0~176.0	0.1	±1.1

Humidity (%RH)

Unit	Measuring range	Resolution	Tolerance
------	-----------------	------------	-----------

			@25°C
%RH	30.0~90.0	0.1	±5.0%RH
%RH	<30.0 , >90.0	0.1	±7.0%RH

По вопросам продажи и обслуживания обращайтесь:

Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Казахстан (7273)495-231

Таджикистан (992)427-82-92-69

Единый адрес для всех регионов: tmv@nt-rt.ru || <https://tenmars.nt-rt.ru/>